

# TEXAS CHRISTIAN UNIVERSITY INFORMATION TECHNOLOGY


## **CRESTORON** USER INFORMATION GUIDE

## Getting Started

Step 1: Touch to Wake Up *(it may be black)*

Step 2: Follow onscreen instructions and touch the screen to begin

Step 3: Press the Source Icon, it will bring the system online




# Computer Use

## Step 1: Select Computer Icon

*\* It may take a few moments for the system to come online*

## Step 2: Enter your TCU username and password to log into the computer

*\* If you're using a wireless keyboard make sure that it is turned on before attempting to login*



...



*\*\* Classroom screen once activated \*\**



## Blu-ray Use

### Step 1: Select Blu-ray Icon

*\*\* If you're switching between systems, give the control panel a few moments and you will see the Blu-ray interface on your device or on the classroom screen*

### Step 2: The panel will now display controls, allowing you to control the Blu-ray functions

*\*\* If the unit doesn't come online when this source is selected, you can hit the power button on the panel to tell it to turn on*





# AirMedia Use

## Step 1: Select AirMedia Icon

*AirMedia allows people to share control of wall monitors and speakers using laptops, and iOS and Android tablets and phones. One user at a time can control the entire screen, or optionally, the screen can be split into four parts with content from up to four computers appearing in each quadrant. **To use this app, you will need to download it at [tcu.edu/airmedia](http://tcu.edu/airmedia).***

## Step 2: Enter the IP address and access code .....




**\*\* AirMedia screen once activated \*\***

## Laptop Use

### Step 1: Select Laptop Icon

Step 2: Connect your laptop to the HDMI cable

*\* It is important that if you do not have a HDMI input on your device, that you have the appropriate adapter to connect to a HDMI cable*



### Note: Computer Settings

Once connected you may have to visit the control panel (Windows) or system preferences (Macintosh) on your computer in order to tell your machine *to display your screen as a mirrored image.*

## Windows

Press Windows logo key  + P

- **PC screen only.** You'll see everything on your PC.
- **Duplicate.** You'll see the same things on both screens.
- **Extend.** You'll see everything across both screens, and you can drag and move items between the two.

## macOS

Click on the **Apple Logo** 

Go to **System Preferences -> Displays -> Arrangement tab**

- **Arrangement** - To arrange your displays, drag one of the displays where you want it. A red border appears around your display as you arrange it. Also called extended mode.
- **Mirror** - With video mirroring, all of your displays show the same apps and windows.

## Document Camera Use

### Step 1: Select Document Camera Icon


If your room is equipped with a document camera, it will normally be off to the side on a rolling cart.

### Step 2: Plug the device into the rack


If you happen to have a ceiling mounted camera, the control panel will give you icons that will allow you to zoom and focus the image.

### Step 3: Plug the device into power

You may have to focus the image based on the type of material you're displaying.




## Advanced Settings



**Note:** Every classroom is equipped a little differently, so your settings and menu options may vary between classrooms.





## IMPORTANT

**Turn off the projector and display once you are finished using for classroom use by pressing the power button**

*This will reset the default source back to the computer.*

*If you need to restart, give the system 15 to 20 seconds before turning it back on in order to allow the entire system to power down properly.*

## A. Display Control

- Turn image display on/off
- Allows for displaying two different sources at the same time if your classroom is equipped with dual displays

*\*\* For example, a Blu-ray player and Air Media*

## B. Camera Control

- Control camera direction
- Zoom in/out
- Auto Focus
- Select between Cam 1 and Cam 2

*\*\* Not all classrooms have two cameras, so this may not be available*

## C. Volume Control

- Control wireless microphone volume
- Assisted listening wireless volume

*\*\* Classrooms of 50 or more are equipped with assisted listening systems or microphone systems*



INFORMATION  
TECHNOLOGY